

Brackets for Headlights

Sumo 3 (HL-EL930RC) / Sumo 2 (HL-EL920RC)
 Volt1600 (HL-EL1010RC) / Volt1200 (HL-EL1000RC) / Volt800 (HL-EL471RC) /
 Volt700 (HL-EL470RC) / Volt400 (HL-EL461RC) / Volt300 (HL-EL460RC) /
 Volt200 (HL-EL151RC) / Volt100 (HL-EL150RC)
 Nano Shot+ (HL-EL625RC) / Nano Shot (HL-EL620RC)
 Econom Force (HL-EL540RC / HL-EL540)
 Econom (HL-EL340RC / HL-EL340) / INOU (MSC-GC100)
 Uno (HL-EL010) / Jido (HL-AU230) / HL-EL135

FlexTight™
 5338827N
MODEL:H-34N

Sumo 2 (HL-EL920RC)
 Volt1600 (HL-EL1010RC) / Volt1200 (HL-EL1000RC) / Volt800 (HL-EL471RC) /
 Volt700 (HL-EL470RC) / Volt400 (HL-EL461RC) / Volt300 (HL-EL460RC) /
 Volt200 (HL-EL151RC) / Volt100 (HL-EL150RC) / Volt50 (HL-EL460RC-REAR)
 Nano Shot (HL-EL620RC)
 Econom (HL-EL340RC / HL-EL340)
 Uno (HL-EL010) / Jido (HL-AU230)
 HL-EL135 / INOU (MSC-GC100)

Helmet Mount
 5341831N

Sumo 3 (HL-EL930RC) / Sumo 2 (HL-EL920RC)
 Nano Shot+ (HL-EL625RC) / Nano Shot (HL-EL620RC)
 Econom Force (HL-EL540RC / HL-EL540) / Econom (HL-EL340RC / HL-EL340)
 Volt1200 (HL-EL1000RC) / Jido (HL-AU230) / INOU (MSC-GC100)

5338880
MODEL:H-32

5338825
 For Oversize Handlebar
 ø28 - 31.8 mm
MODEL:H-31

Volt150 (HL-EL460RC-REAR)
 FlexTight™
 Bracket
 5342430
MODEL:SP-13

RM-2
 Bracket
 5342420

Volt1600 (HL-EL1010RC) / Volt1200 (HL-EL1000RC) / Volt800 (HL-EL471RC) /
 Volt700 (HL-EL470RC) / Volt400 (HL-EL461RC) / Volt300 (HL-EL460RC) /
 Volt200 (HL-EL151RC) / Volt100 (HL-EL150RC)
 Nano Shot+ (HL-EL625RC) / Nano Shot (HL-EL620RC)
 Econom Force (HL-EL540RC / HL-EL540) / Econom (HL-EL340RC / HL-EL340)
 Uno (HL-EL010) / Jido (HL-AU230) / HL-EL135

Center Fork Bracket
 5342440
MODEL:CFB-100

Volt6000 (HL-EL6000RC)

Light Unit
 5343020

FlexTight™ Bracket
 5338829N
MODEL:H-34N HP

Helmet Mount
 5341832N
MODEL:Helmet mount HP

Control Unit
 5343040

Battery Unit
 Li-Ion 14.4V 6800mAh:BA-608
 5343030
MODEL:BA-608

Fixing Strap
 5343050

Auxiliary Strap
 5342180

Extension Cable
 5343080

Cable Cover
 5342190

Remote Control Switch
 5343070
MODEL:WSW-001

Rubber Band
 5447010

Battery Charger
 5343060

Volt Series (HL-EL1010RC / HL-EL1000RC / HL-EL471RC / HL-EL470RC / HL-EL461RC / HL-EL460RC / HL-EL460RC-REAR / HL-EL151RC / HL-EL150RC)

USB Cable (Micro USB)
 5342730

Volt1600 (HL-EL1010RC)
 Cartridge Battery
 Li-Ion 3.6V 6800mAh: BA-6.8
 5342611

Volt1600 (HL-EL1010RC)
 Volt800 (HL-EL471RC)
 Volt400 (HL-EL461RC)
 Volt200 (HL-EL151RC)

Volt1600 (HL-EL1010RC)
 Volt800 (HL-EL471RC)
 Volt700 (HL-EL470RC)
 Volt400 (HL-EL461RC)
 Volt150 (HL-EL460RC-REAR)

Volt700 (HL-EL470RC)
 Volt400 (HL-EL461RC)
 Volt300 (HL-EL460RC)
 Volt150 (HL-EL460RC-REAR)

Fast Charging Cradle 2
 (USB Cable Attached)
 5342620
MODEL:CRA-002

Fast Charging Cradle
 (USB Cable Included)
 5342720
MODEL:CRA-001

Volt800 / 700 / 400 (HL-EL471RC / HL-EL470RC / HL-EL461RC)
 Cartridge Battery
 Li-Ion3.6V
 3100mAh : BA-3.1
 5342680

Volt1400 / 300 / 50 (HL-EL461RC / HL-EL460RC / HL-EL460RC-REAR)
 Cartridge Battery
 Li-Ion3.6V
 2200mAh : BA-2.2
 5342710 Black
 5342711 White
 5342712 Silver

Volt80 (HL-EL050RC)

Rubber Band And Hook
 5441621

Rubber Cap
 5342850

Sumo 3 (HL-EL930RC) / Sumo 2 (HL-EL920RC)

Battery
 Charger
 UL:5342300
 AS:5342304
 EC:5342302
 UK:5342301

BA-904 Battery Unit
 Li-Ion / 7.4V
 4600mAh
 5342140

BA-908 Battery Unit
 Li-Ion / 7.4V
 9200mAh
 5342130

Light Unit
 Sumo 3
 5342150

Light Unit
 Sumo 2
 5342160

Extension Cable
 5342290

Fixing Strap
 5342170

Auxiliary Strap
 5342180

Cable Cover x 3
 5342190

Sumo's battery unit and battery charger are compatible with Triple Shot Pro HL-EL830RC and Double Shot Pro HL-EL820RC.

Econom Force (HL-EL540RC / HL-EL540)

Special
 Nickel-Hydrate
 Rechargeable
 Battery x 4
 5341891

Battery Charger
 CHA-2.2AH-4.8V
 UL : 5336760
 UK : 5336761
 EC : 5336762
 AS : 5336763
 *Can be used with 5341891 only.

Econom (HL-EL340RC / HL-EL340)

Special
 Nickel-Hydrate
 Rechargeable
 Battery x 4
 5341890

Battery Charger
 CHA-2.2AH-2.4V
 UL : 5341880
 UK : 5341881
 EC : 5341882
 AS : 5341884
 *Can be used with 5341890 only.

Nano Shot+ (HL-EL625RC) Nano Shot (HL-EL620RC)

Mini USB Cable
 5342760

Brackets and Mount Parts for Safety Lights

Rapid 3 / 1 (TL-LD630-F / TL-LD611-F)
 Omni 5 (TL-LD155-F) / TL-LD150-F
 Omni 3 (TL-LD135-F) / TL-LD130-F
 Solar (SL-LD210-F)

FlexTight™
 5342400
 ø22.2 - 32 mm
MODEL:SP-12-F

Rapid 5 / 3 / 3 Auto / 1 (TL-LD650-R / TL-LD630-R / TL-AU630-R / TL-LD611-R)
 FlexTight™
 5342410
 ø21.5 - 32 mm
MODEL:SP-12-R

Rapid Series
 Blitz Auto (TL-AU330)
 Omni 5 (TL-LD155-R / -F) / TL-LD150-R / -F
 Omni 3 (TL-LD135-R / -F) / TL-LD130-R / -F
 Solar (SL-LD210-R / -F)

FlexTight™
 5342280
 ø12 - 32 mm
MODEL:SP-11

Rapid Series
 Blitz Auto (TL-AU330)
 Omni 5 (TL-LD155-R / -F) / TL-LD150-R / -F
 Omni 3 (TL-LD135-R / -F) / TL-LD130-R / -F
 Solar (SL-LD210-R / -F)

FlexTight™
 5342260
 ø13 - 32 mm
MODEL:SP-10

Rapid Series
 Reflex Auto (TL-LD570-R / -F)
 Reflex (TL-LD560-R / -F)
 Blitz Auto (TL-AU330)
 Omni 5 (TL-LD155-R / -F) / TL-LD150-R / -F
 Omni 3 (TL-LD135-R / -F) / TL-LD130-R / -F
 Solar (SL-LD210-R / -F)

Clip
 5440900N
MODEL:C-1N

Clip
 5342460
MODEL:C-2

Rapid Series
 Reflex Auto (TL-LD570-R)
 Reflex (TL-LD560-R)
 Blitz Auto (TL-AU330)
 Omni 5 (TL-LD155-R) / TL-LD150-R
 Omni 3 (TL-LD135-R) / TL-LD130-R
 Solar (SL-LD210-R)

Rear Rack
 Bracket
 5445620

Rear Rack
 Bracket
 5342250

Rapid Series
 (TL-LD650 / TL-LD635-R / TL-AU630-R / TL-LD611-R)
 Omni 5 (TL-LD155-R) / TL-LD150-R
 Omni 3 (TL-LD135-R) / TL-LD130-R

Saddle Rail Mount
 5446510
MODEL:RM-1

Rapid 5 / 3 / 3 Auto / 1
 (TL-LD650-R / TL-LD630-R / TL-AU630-R / TL-LD611-R)
 SR-2 Bracket
 (For Fi zi:k ICS-Compatible Saddles)
 3980060

Rapid Series
 Reflex Auto (TL-LD570-R / -F)
 Reflex (TL-LD560-R / -F)
 Omni 5 (TL-LD155-R / -F)
 TL-LD150-R / -F
 Omni 3 (TL-LD135-R / -F)
 TL-LD130-R / -F
 Solar (SL-LD210-R / -F)

5440980

TL-LD170-R / -F
 5440893
MODEL:L-1

5440894

MODEL:L-2

TL-LD260-F
 5441050

Reflex Auto (TL-LD570-F)
 Reflex (TL-LD560-F)
 5445610

Rapid X3 (TL-LD720-R / -F)
 Rubber Base
 5447050

Rapid X2 (TL-LD710-R / -F)
 Rubber Base
 5447030

Rapid X (TL-LD700-R / -F)
 Rubber Base
 5447020

Rapid X3 (TL-LD720-R / -F)
 Rapid X2 (TL-LD710-R / -F)
 Rapid X (TL-LD700-R / -F)

Spacer X
 5342470

Rubber Base For Sharp Aero
 5447040

Nima 2 (SL-LD135-R / -F)
 Loop 2 (SL-LD140RC / SL-LD140)

Rubber Band
 And Hook
 5441621

Lithium Battery
 1665150
CR2032

Nima (SL-LD130-R / -F)
 Rubber Band
 5441620

Lithium Battery
 1665150
CR2032

Volt150 (HL-EL460RC-REAR)
 Saddle Rail Mount
 5342420
MODEL:RM-2

FlexTight™
 5342430
 ø22.2-32 mm
MODEL:SP-13

Rapid X3 (TL-LD720-R / -F)
 Rapid X2 (TL-LD710-R / -F)
 Rapid X (TL-LD700-R / -F)

Rubber Band
 5447010

Rapid X3 (TL-LD720-R / -F)
 Rapid X2 (TL-LD710-R / -F)
 Rapid X (TL-LD700-R / -F)

Rapid mini (TL-LD635-R)
 Loop 2 (SL-LD140RC-R / -F)
 USB Cable
 (Micro USB)
 5342730

Rapid 1 (TL-LD611-R / -F)
 Mini USB Cable
 5342760

Rapid mini (TL-LD635-R)
 Bracket
 5342450
MODEL:SP-14-R

Orbit 2 (SL-LD150)
 Lock Nut
 5442160

Clamps

TL-LD150-R / TL-LD170-R

BS-3

BS-3N

BS-5

Rapid Series / Reflex Auto (TL-LD570-R / F) / Reflex (TL-LD560-R / F) / TL-LD170 / TL-LD150 / TL-LD130 / Solar (SL-LD210) / TL-LD260-F

HP-5

SP-5

SP-6

SP-7

SP-8

SP-9

5440892
 Universal Clamp

ø12.7 - 13.6 mm

ø12.7 - 16 mm

ø15.5 - 16.5 mm

ø19 - 22.8 mm

ø23.5 - 27.2 mm

ø26.5 - 30.2 mm

ø28.8 - 32.5 mm

ø31.5 - 34.5 mm

ø34.5 - 37.5 mm

ø18 - 40 mm